



How to Install LABEL Driver

1. Double click LABEL.dmg.


2. Double click LABEL_V1.0_signed.pkg to install the driver.




3. Click "Continue" button.




4. Click "Install".




5. Use Touch ID or Enter your password.




6. Click "Close" to finish.




7. Open "System Preferences", and click "Printers & Scanners".




8. Click "+" to add a new printer.




9. Turn on your printer, you will see "LABEL -9X20".




10. Click "LABEL -9X20", and then click "Choose a Driver..."




11. Click “Select Software...”.




12. Select “LABEL” and then click “OK”.



13. Click "Add".




14. Finish.




How to change the setting of the printer, and how to define the label size (Preview)


1. Open a PDF file (any document file is ok), Select “File”-->”Print”.




2. Choose “Manage Custom Sizes...” under “Paper Size ” drop down menu.




3. Click “+” to define a new label size, click “OK” to save.



4. You can select the new Label “100*190” now.



5. Select “Printer Features”, then you can change the setting of printer, for example: Print Speed, Darkness.



6. Click “Print”.